


Rimage AutoEverest™ Setup and Installation

1 **Unpack the Everest printer.**

To unpack the **Everest printer**, refer to the *Everest Unpacking and Setup Instructions* included with your Everest printer.

2 **Install the Everest printer.**

Place the **Everest printer** on the AutoPrinter so the plastic feet slide into the slots on the printer plate.



3 **Connect the cables.**

- Connect the **printer cable** from the AutoPrinter to the Everest printer.
- Connect the **short power cord** from the AutoPrinter to the Everest printer.
- Connect the **power cord** from the AutoPrinter to a power outlet.
- Connect the **USB cable** from the Everest printer to the computer.



4 **Install the printer driver.**

For detailed instructions, refer to the *Everest Printer User Guide*.

5 **Install the CD Designer Software Suite.**

- ⚠ **Important!** CD Designer is not Macintosh® compatible. This step applies only if you are installing the AutoEverest on a Windows-based PC.

With the CD Designer Software Suite disc in the PC disc drive, navigate to **Setup.exe** and follow the prompts to install the software.