



P11 Driver Installation for Windows Vista


1. Execute the “P11 Vista Driver Install.exe.” This is a self-extracting program and it will decompress all the required files for installation into the “C:\ P11 Vista Driver Install” folder.
2. Open the “P11 Vista Driver Install” folder and double-click on the CD-DVD Printer icon.
3. Follow the instructions on screen and install the “CD/DVD Application”.
Note: Depending on your PC configuration, the display screen may not be the same as shown in the picture below.
4. The InstallShield Wizard will guide you through the program setup. Click **Next**. The InstallShield will search for the CD-DVD Application on your PC.




5. Enter your User Name & Organization. Click **Next**.




6. The InstallShield Wizard is ready to install the CD-DVD Application on your PC. Click **Install**.




- The InstallShield Wizard will install the CD-DVD Printer Application to the PC.




- Windows Vista will prompt you to allow to continuing run the program. Go ahead and allow continuing the installation.
- The Device Driver Installation Wizard finds the device driver for the P-11 printer. Click **Next**.



- The device driver installation is complete. Click **Finish**.



11. The CD-DVD Application installation is complete. Click **Finish**.



12. Windows Vista detects and installs the device driver successfully. Click **Close**.

